Combi

Baby Keep WA Corner Mounting Kit Installation Manual

For Corner Installation Use To Be Used With : Baby Keep Slim WA (Model BK-W62)

In order to safely install the Baby Keep WA, please make sure to read this manual and follow the instructions accordingly. This guide explains how to attach the Baby Keep Slim WA to a corner. To attach the Baby Keep FL type to a wall, please to the Installation Manual connliad with the Dahy Koon El. tune

refer to the Insta	llation Manual sapplied with the E	3aby Keep FL type.			
		Safety Warnings			
		gs" and "cautions" according to the un nanual carefully before use, and obser	rgency and seriousness of the harm and		
		ndled, there is risk of serious injur			
CAUTIONS		ndled, there is risk of injury or pro			
			perty uaillage.		
		A WARNING			
		r bolts can be firmly placed into the wa	all. (Failure to do so may result in fall.)		
must be embe	the anchor bolts edded at least e wall. Failure to Anchor — E	Correct Concrete Tile Mortar	Tile 40 mm or greater Secure the anchor bolts firmly into concrete, to a depth of at least 40mm. Mortar Concrete		
		th of 1,000 N (100 kgf or more)[fix 4 mount	ing points]. Failure to do so may result in fall.		
	<u>.</u> .	rews used for Wall-mounting	g in the second s		
	the following before installation:	oncrete/ALC Installation			
	Female screw anchor bolts Use ALC-specific anchors for ALC installation Bolts → □ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	4 large holes	CAUTION Do not use male screw anchor bolts.		
	Installation	Location (Installation Range	e)		
o assist the ch o not install th rom the caregi <u>M</u> WA	ne unit far Location ver. RNING	Prevent from escaping	WARNING Below the seating surface, as described in the diagram on the left, do not place handrails (including hinged one), trash can, or other objects. The child may stand up and escape and may fall.		
can see the child.)	300mm			
600mm as standa	• Install on a wall at least 600mm away from the toilet, or insure 300mm of space between the Baby Keep FL and toilet.				
		A WARNING	A CAUTION		
Not interfere with Install the Baby Ke least 300mm from the toilet	ep at	If installing the Baby Keep FL in a private restroom, install the Baby Keep FL in a location where the child can be seen by the adult using the restroom at all times.	The Baby Keep FL should be installed clearly from door space. Otherwise it may cause damage.		

Routine Safety Inspection

*Guide stickers, 2



Conduct the daily and annual safety inspections described below in order to safely use this product. Injury or serious accident could occur if safety inspections are not performed and/or problems with the product are not observed.

The daily or weekly inspection is a check using both eyes and hands. No tools are necessary.

1. Physical Inspection

1. Check for loose parts

- 2. Make sure the base does not wobble or shake,
- and that the guard is firmly in place
- 3. Check for scratches or broken parts

2. Checking the Guard's Function

- 1. Insure that the quard is firmly in place, does not wobble or shake, and moves from left to right.
- 2. After testing the opening and closing function of the guard several times, insure that neither the base nor the guard wobbles or shakes.

3. Sticker Check

Stickers should be firmly adhered and legible. Check for scratches, rips, missing stickers, or fadedness.

4. Head and Seat Pad Check

Check for scratches and broken parts. Make sure the head and seat pads do not wobble or shake.

For more information regarding the maintenance inspection (additional cost) and repair parts (sold separately

- Main maintenance parts include pads and decals.
- Product durable period is 7 years. Repair Parts available with in 5 years after end of production.

	Technical Sp	ecific
Product Number	BC-W31	W
Product Name	Corner Mounting Kit	Ma
Dimensions	W205×D65×H623.5mm	

*Be advised that technical specifications for this product may change without notice for reasons such as improvement in design.

Manufacturer Combi Corporation

2-6-7, Motoasakusa, Taito-ku, Tokyo 111-0041 Japan



